

Custom 4x4 Fabrication

11825 S.E. 109th
Oklahoma City, OK 73165
(405) 799-7599
custom4x4fabrication.com

INSTALLATION INSTRUCTIONS FOR CHEROKEE TOW HOOK BRACKETS

THIS KIT INCLUDES THE FOLLOWING:

- A - 2 TOW HOOK BRACKETS
- B - 2 ANGLE BRACKETS
- C - 1 HARDWARE KIT

AFTER REMOVING THE FACTORY FRONT BUMPER AND BRACKETS FOLLOW THE STEPS BELOW:

STEP 1:

INSTALL THE TWO ANGLE BRACKETS (*PART B*) TO THE FRONT CROSS MEMBER USING TWO M10 X 1.5 X 30 METRIC BOLTS PER SIDE.

STEP 2:

REINSTALL FACTORY BUMPER BRACKETS WITH THE TOW HOOK BRACKETS (*PART A*) IN-BETWEEN THE UNIBODY AND THE FACTORY BRACKETS USING THREE M10 X 1.5 X 30 METRIC BOLTS AND ONE 1/2 X 13 X 3 1/2 BOLTS PER SIDE.

STEP 3:

REINSTALL FRONT BUMPER.

NOTE: 97+ CHEROKEES WILL REQUIRE TRIMMING OF THE FRONT AIR DAM TO ACCOMMODATE THE TOW HOOKS.

ENJOY YOUR NEW CUSTOM 4X4 FABRICATION TOW HOOK BRACKETS!!!